



QUICK START GUIDE


Getting Started

Thank you for choosing the **Orbic SPEED X® 5G Hotspot**.

The device's 5G capabilities offer a secure reliable Wi-Fi connection whether you are working from home or traveling.














This guide provides the basic operations of your mobile hotspot.

Device Overview



Note: The 1Gbps Ethernet port is disabled by default to extend battery life. To enable it, select **Enable Ethernet Port** from **Menu > Settings** on the touchscreen, or **Settings > Preferences** on the Admin web UI.

Device indicator display

Indicator	Status
	Home
	Network Signal Strength
	Data transferring between mobile network and hotspot
	Roaming
	Unread Messages
	Hotspot Wi-Fi network
	Connected devices
	USB Tethered
	Battery Fully Charged
	Battery critically low and hotspot will shut down unless charged
	Hotspot connected to AC charger and charging
	Hotspot Battery Preservation Mode
	Ethernet port enabled

Setting up your 5G hotspot

Pre-installed 5G SIM

For optimal functionality of your new device, please use the pre-installed SIM card.


Turning your Hotspot ON/OFF

Important: Before you use your hotspot, charge the battery for at least four hours to ensure fully charged.

1. Press and hold the **Power** button for three seconds to power on.
2. To turn it off, press and hold the **Power** button for three seconds until you see the Powering Off screen. Then select **Shutdown** and tap **OK**.
3. Press and release the **Power** to wake up the display.

Finding Wi-Fi name and password

1. Tap Wi-Fi Name/Password on the Home screen.



2. The information for your primary network will be shown.
3. Swipe left to see the info for your guest network.

Connecting to the internet

On your Wi-Fi capable device, open the list of available Wi-Fi networks. Select the hotspot primary or guest network and enter the password.

Managing Wi-Fi networks and connections

Your 5G hotspot has two Wi-Fi networks, primary and guest, and lets your connect up to 32 Wi-Fi capable devices. For added security, share your guest network instead of your primary network.

The guest network is off by default. You can turn it on from either the touchscreen or the Admin web UI by assigning it a band in **Wi-Fi > Settings > Band Selection** (see Accessing advanced settings).

Accessing Advanced Settings

You can access advanced settings and manage your hotspot from the Admin web UI:

1. Connect your device to the primary network (see Connecting to the internet).

2. Open a web browser on your connected device and enter **http://my.mobilehotspot** or **http://192.168.1.1**
3. Sign in with the Admin password. When you first get your 5G hotspot, this is the same as your primary network's password (see Finding the Wi-Fi name and password).

Monitoring Data Usage


You can monitor your hotspot data usage and set up usage alerts through your My Verizon account at **verizon.com/MyVerizon**. You can also see current usage details on the Home screen of your hotspot, or by tapping **Menu > Data Usage**.

Resetting your Hotspot

You can reset your 5G hotspot to factory settings from the touchscreen or from the Admin web UI.

Note: Resetting your hotspot will disconnect devices and reset network names and passwords. To reset using the reset hole:

1. Make sure your hotspot is on.
2. Remove the battery cover from the back of your hotspot.
3. Insert an unfolded paper clip into the **Reset** hole and press until the hotspot screen shows **Resetting**.



Reset hole

Additional Information

System Requirements

Any device with Wi-Fi capability and an internet browser. Your 5G hotspot is compatible with all major operating systems.

Your wireless device and third-party services

Verizon Wireless is the mobile carrier associated with this wireless device, but many services and features offered through this device are provided by or in conjunction with third parties.

Verizon Wireless is not responsible for your use of this device or any non-Verizon Wireless applications, services and products, including any personal information you choose to use, submit or share with others. Specific third-party terms and conditions, terms of use and privacy policies apply. Please review carefully all applicable terms conditions and policies prior to using this wireless device and any associated application, product or service.

Support and More



From your computer,
visit **verizon.com/Support**



Customer service

Call 800.922.0204

X(Twitter): @VerizonSupport

Facebook: @Verizon



Download a user Guide
from **verizon.com/Support**



Product Safety and Warranty
Information

For full details, visit **Orbic.us**



V12