



QUICK START GUIDE

Getting Started

Thank you for choosing the Orbic Trophy 5G.

This guide helps you to get started with your device for the first time.

Phone Features



NOTE: The screen images and icons here are for reference only and are subject to updates.




Your phone already has a SIM card installed. For optimal functionality of your new device, please use the pre-installed SIM card.

Inserting MicroSD Card

If you have a microSD card, use the pin tool and insert it in the hole to release the tray. Insert the microSD card with the gold contacts facing down. Close the tray.

NOTE: The microSD card is sold separately.



Charging the Battery

Before using your device, Orbic recommends to fully charge the battery (100%).

1. Insert one end of the charging cable (USB Type-C) into the device and the other end of the charging cable into the charger adapter.
2. Plug the charger into an electrical outlet that is close to the device and is easily accessible.

Warning! Use only approved chargers with your device. Incompatible chargers may damage the device and void the warranty.



Turning your Phone ON/OFF

To Power ON/OFF Your Device

To turn ON

- Press and hold the **Power/Lock** key.

To turn OFF

- Simultaneously press and hold the power and volume up keys. Follow the prompts and select **Power off**.



Using On-screen Gestures

Use the on-screen gestures to move around the screen, open menus, select items, zoom in or out on web pages, and more.

- **Tap** - To open an app, select a menu item, press an on-screen button, or enter a character using the keyboard on the screen, tap it with your finger.
- **Touch and hold** - Touch and hold an item or the screen for more than 2 seconds to access available options.
- **Drag** - To move an item, touch and hold it and drag it to the target position.
- **Double-Tap** - Double-tap on a web page or image to zoom in. Double-tap again to return.
- **Swipe** - Swipe to the left or right on the screen to scroll sideways. Swipe upwards or downwards to scroll through a web page or a list of items.
- **Spread and Pinch** - Spread two fingers apart on a web page, map, or image to zoom in on a part. Pinch to zoom out.


Locking and Unlocking the Phone

To Lock the Screen

- Press the **Power/Lock** key. This action prevents accidental keypresses.

To Unlock the Screen

- Press the **Power/Lock** key and swipe up on the screen.



Setting Up Email Accounts

- Tap the **Home key** ● > swipe up for **Apps** > **Settings**  > **Passwords & accounts** > **+ Add account**.
- Tap the type of account you want to add.
- Enter your email address and password.
- Follow the on-screen instructions to set up your email account.

Making and Receiving a Call

1. From the Home screen, tap  > .
2. Enter the number you want to call or the first letter of the contact's name and select the contact.
3. Tap  to place the call.

To receive a call,

1. Swipe the  up to answer an incoming call.

Sending a Text Message


1. From the Home screen, tap  >  to compose a new message.
2. Enter the recipient's name or number in the **To** field.
3. Enter the text message.
4. To add an attachment, tap .
5. Tap  SMS to send your message.

Camera

Taking photos

1. From the Home screen, tap .
2. Aim the camera at the subject using the device's main display screen as a viewfinder.
3. Pinch to zoom in and spread 2 fingers apart to zoom out.
4. Before taking a photo, you can tap on the screen icons to access various camera options and settings, if required.
5. Tap  to capture a photo.

NOTE: You can also use the volume keys to capture a photo.



Recording videos

1. From the Home screen, tap .
2. Tap **Video** on the screen to switch to video mode.
3. Aim the camera at the subject using the phone's main display screen as a viewfinder.
4. Pinch to zoom in and spread 2 fingers apart to zoom out.
5. Tap  to start recording a video.

Google™ Play Store

Find and download your favorite apps, movies and TV shows, music, books, magazines, and games. Google™, Google™ Play, and Android™ are trademarks of Google™ LLC.

Installing the Apps

Your device comes preloaded with several applications, and you can download many more from the **Play Store** .

NOTE: The Play Store is an application that comes preinstalled on Android™ devices.

To install applications from the Play Store

1. Search or browse for applications.
2. Select the desired app, download, and install.
3. Follow the on-screen instructions to complete the installation.
4. You can also uninstall, update and manage your downloaded apps.

Uninstalling the Apps

1. Touch and hold the app icon that you want to uninstall.
2. Tap **App info**, then select **Uninstall** and follow the prompts to uninstall the app.
3. Tap **OK** to confirm or **Cancel** to stop the uninstallation.

NOTE: Some of the preloaded apps on the device cannot be uninstalled.

Improving Accessibility

Accessibility options are special features that make using the device easier for people who are physically handicapped.

To set accessibility options

1. Tap **Home key** ● > swipe up for **Apps** > **Settings**  > **Accessibility**.
2. Tap a category and set the desired options.

Connecting to Wi-Fi

1. Tap **Home key** ● > swipe up for **Apps** > **Settings**  > **Network & internet** > **Internet**. Make sure the **Wi-Fi** is turned ON.
2. Select a displayed network, enter its password, and select **Connect**.
3. If your desired network isn't displayed, tap + **Add network**. Enter the network SSID and other required information. Tap **Save**.

Verizon Cloud

Verizon Cloud offers secure online storage to back up your contacts and sync them with your other Cloud-Connected devices. For more info, go to: <http://vzw.com/cloud>

Verizon Wireless

Your wireless device and third-party services

Verizon Wireless is the mobile carrier associated with this wireless device, but many services and features offered through this device are provided by or in conjunction with third parties. Verizon Wireless is not responsible for your use of this device or any non-Verizon Wireless applications, services and products, including any personal information, you choose to use, submit or share with others. Specific third-party terms and conditions, terms of use and privacy policies apply. Please review carefully all applicable terms conditions and policies prior to using this wireless device and any associated application, product or service.

HAC Information

Hearing aid compatibility information

This phone has been tested and rated for use with hearing aids for some of the wireless technologies that it uses. However, there may be some newer technologies that have not been tested yet for use with hearing aids. It is important to try the different features of this phone thoroughly and in different locations, using your hearing aid or cochlear implant, to determine if you hear any interfering noise. Ask your service provider or the manufacturer of this phone for information on hearing aid compatibility. If you have questions about return or exchange policies, ask your service provider or phone retailer.

Support and More



From your computer, visit
verizon.com/support



Customer service
Call: 800.922.0204
X(Twitter): @VerizonSupport
Facebook: @Verizon



Download a user Guide from
verizonwireless.com/Support



My Verizon Mobile App

Manage your account, track your usage, edit account information, pay your bill and more.



Product Safety and Warranty Information
For full details, visit
Orbic.us